

CHEERICO

SQUARE Acrylic Cupcake Stand

Thank you for purchasing one of our acrylic products. Please follow the guide below to ensure your product is assembled correctly and avoid potential damage.

PLEASE NOTE: You must remove the manufacturer's protective cover before assembling this product. This covering is clear bubble and cling wrap on both sides of every acrylic component.

ASSEMBLY GUIDE:

Parts: Acrylic discs, head screws, acrylic rods and acrylic feet.

1. Remove the manufacturer's protective cover from BOTH side of each acrylic component.
2. Take 4 metal head screws and place under the bottom disc on to a flat surface where the stand is to be constructed
3. Now screw the 4 acrylic rods onto the screw thread of the head screw making sure the acrylic disc is clamped firmly between two components.
4. Begin by placing the acrylic feet to the underside of the bottom disc ensuring they are evenly spaced.
5. Carefully line up the hole(s) of the largest disk with 4 head screws ensuring the disc is resting securely on the acrylic feet.
6. Continue by placing the next largest disc on to the screw thread of rods and tighten each piece as you go.
7. Tighten the final rod and the disc 1 with head screw and the stand is completed.

CARE GUIDE:

- The stand is made from acrylic which will scratch if it is not looked after properly.
- To clean the product use warm water with a little washing-up liquid and soft cloth.
- Do not use any abrasive cleaning products as they will make the acrylic.
- Do not put the stand in a dishwasher

